



CAUTION!

Battery Safety: This product contains a button battery. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately. SEE ADDITIONAL SAFETY WARNING.

ENGLISH

Thrive LED Sanitizing Lamp with USB Charging

CONGRATULATIONS!
You've purchased the finest in natural lighting technology with your new OttLite® product.
WARNING: To prevent electric shock, make sure the lamp is not plugged in until all steps are complete.

PRODUCT REGISTRATION FORM
Please complete the enclosed Product Registration Form and return it today by mail or register online by going to: OttLite.com/warranty.

NOTE: THIS UNIT IS FULLY ASSEMBLED

1. Remove lamp from packing, placing lamp body base (A) flat on a steady surface.
2. Connect power adapter input (F) into connector (G) in the rear-bottom of the lamp.
3. Plug the power adapter (H) into a standard household 120V AC outlet. **Note: Only use with the supplied power adapter to avoid damage or fire.**
4. Power switch (B) is a "touch" switch that controls ON/OFF power, the LED brightness settings and the mode function of the lamp.
5. To turn the lamp ON, touch (B) once. To adjust brightness touch (B) again. The lamp has 3 brightness settings and then the fourth touch will turn the light OFF.
6. Touch and hold (B) to change light modes. The three modes are; ClearSun LED, Sanitizing, and ClearSun + Sanitizing. ClearSun + Sanitizing mode utilizes both the ClearSun LEDs and Sanitizing LEDs simultaneously to provide continuous cleaning while using the lamp. **NOTE:** The active mode will be indicated by the light next to the icons. If indicator light (I) is illuminated, ClearSun mode is on. If indicator light (P) is illuminated, Sanitizing mode is on. If both indicator lights (I and P) are illuminated, ClearSun + Sanitize mode is on.
7. To reposition the light, hold the lamp base (A) steady and grasp either flex-neck (C) or shade (D) depending on needed adjustment.
8. Refer to diagram 1 for lamp maximum adjustment range. **NOTE: DO NOT FORCE** the shade outside allowable adjustable range as excessive adjustment may cause damage.

REFER TO THE FOLLOWING ICON LEGEND FOR CONTROL PANEL (J), AS IT PERTAINS TO THE INSTRUCTIONS FOR VARIOUS SETTING FUNCTIONS BELOW.

- ⚙️ "SETTING BUTTON" – to set time and calendar; in alarm mode, push to turn off alarm.
- M "MODE BUTTON" – push to set alarm and snooze
- ⬆️ "UP BUTTON" – In setting mode, push to increase.
- ⬇️ "DOWN BUTTON" – In setting mode, push to decrease.

CALENDAR AND CLOCK SETTING:

- NOTE:** Control Panel (J) to set Calendar and Clock is located on the bottom of lamp body base (A). **NOTE:** For clock operation layout and features, see diagram 2.
- Under normal mode, press "SETTING BUTTON" to enter setting mode, press "SETTING BUTTON" again for next setting. The sequence of setting is: HOUR – MINUTE – YEAR – MONTH – DAY.
 - In setting mode, press "MODE BUTTON" to quit setting, or it will automatically quit to normal mode if idle for 60 seconds.
 - Under normal mode, press "UP BUTTON" to switch between "12h" and "24h" display

ALARM & SNOOZE FUNCTION SETTING:

- Under normal mode, press "MODE BUTTON" to enter alarm mode, indicated on screen by icon (R).
- Under alarm mode, press "SETTING BUTTON" to enter alarm setting, press "SETTING BUTTON" again for next setting, the sequence of setting is: HOUR – MINUTE – SNOOZE – MUSIC and then exit.
- NOTE:** There are 8-music tones to select.
- Press and "UP BUTTON" and "DOWN BUTTON" to adjust alarm time sequence.
- Under alarm mode, press "UP BUTTON" and "DOWN BUTTON" to turn ON/OFF alarm and snooze function. "MUSIC NOTE" icon will light up on the display to indicate alarm is set. "Zzz" will appear on the display to indicate snooze is activated.
- When alarm time reached, alarm will ring for 1-minute, then snooze and ring again. Press "SETTING BUTTON" to turn OFF alarm or touch "UP BUTTON" and "DOWN BUTTON" to activate snooze. **NOTE:** Snooze defaults to 60-minutes, if loss of power occurs.

BATTERY REPLACEMENT

- This lamp uses a CR2032 battery. For battery replacement see diagram 3.
- Battery compartment (K) is located on the bottom of lamp body base (A).
- To remove/install button cell battery: use a screwdriver to remove battery compartment door (M). Button cell battery is to be installed with the "+" or flat side facing upward.

BATTERY DISPOSAL:

- Battery disposal should be in compliance with local regulations pertaining to the disposal of hazardous materials. **DO NOT INCINERATE.**

SAFETY WARNING:

- **CAUTION: DO NOT INGEST BATTERY; CHEMICAL BURN HAZARD!**
 - This lamp contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just two hours and can lead to death.
 - Keep new and used batteries away from children.
 - If the battery compartment does not close securely, stop using the product and keep it away from children.
 - If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- NOTE:** Coin/button cell batteries are small, single cell devices having a diameter greater than their height.

SAFETY WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

1. Turn lamp off and **WAIT UNTIL LAMP HEAD (D) IS COOL** before handling.
2. The LED panel (E) might get hot after several hours of continuous use **DO NOT** place your hands directly on LED light panel.
3. Never use with an extension cord unless the plug can be fully inserted into the receptacles in the extension cord.
4. Do not alter the plug.
5. The lamp head included with this unit cannot be replaced by the consumer.

NOTE: The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

CAUTION! IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE IS DAMAGED, IT SHALL BE EXCLUSIVELY REPLACED BY THE MANUFACTURER OR ITS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON IN ORDER TO AVOID A HAZARD. INDOOR USE ONLY.

CAUTION! THE LIGHT SOURCE OF THIS LUMINAIRE IS NOT REPLACEABLE; WHEN THE LIGHT SOURCE REACHES ITS END OF LIFE THE WHOLE LUMINAIRE SHALL BE REPLACED.

FCC PART 15

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-005 (B)/NMB-005 (B)

CAUTION: Any change or modification to product not expressly recognized by OttLite Technologies voids OttLite's responsibility for proper function of product.

POWER ADAPTER SPECIFICATION:
Input: AC 100-240V, 50/60 Hz, 0.8A
Output: 12V DC, 2.0A with a Male DC Plug

THIS LAMP CONTAINS A 5V, 2.1A USB output port (L) located on the bottom rear of lamp. USB port can charge items such as tablets, cellular phones, etc.

Thrive LED Sanitizing Lamp with USB Charging
SCEY700S



C8USC

INS200594

REV090320